


Extension Socket Contact Adapter

Installation Guide (G-EXT-1.5-SC, G-EXT-3-SC, G-EXT-4.5-SC, G-EXT-6-SC and G-EXT-9-SC)



Recommended Tools

- 1—10 " Adjustable Wrench
- 1—3/4" combination wrench

1. Remove equipment port caps and loosen seizure screws to accept adapter pin. Verify length and, if necessary, trim the adapter pin to equipment manufacturer's specification.





2. Using the trim gauge provided on the adapter, trim the pin of the entry connector to the required length. (See Figure A and B).

3. Screw the entry connector body into the adapter entry port. Using two wrenches tighten until a firm stop is reached (See Figure C).

4. Install the adapter into the equipment's port. Using a wrench tighten until a firm stop is reached. (See Figure D).

5. Complete entry connector installation onto cable per manufacturers instructions.

6. Tighten seizure screws inside of the equipment as recommended by the equipment manufacturer. Replace port caps. (See Figure E).



Corning Gilbert Inc.
Broadband Products

5310 W. Camelback Rd.
Glendale, AZ 85301 U.S.A.

phone: 800 528 5567 (U.S. and Canada)
623 245 1050 (International)

fax: 800 344 6358
623 939 3538

website: www.corning.com/corninggilbert
e-mail: info-gilbert@corning.com