

Trunk & Distribution Adapters

Housing to Housing Locking Installation Guide



Applicable Part Numbers G-KS-KS-MLK-T

Recommended Tools

- 1 −10" Adjustable Wrenches
- 1-3/4" Open End Wrench
- 1 —Screwdriver
- 1 —Pin Cutters
- 1. Remove equipment port caps and loosen seizure screws to accept pin. Verify pin length and, if necessary, trim each end of the pin to equipment manufacturer's specification.
- 2. Loosen the Coupling Nut until it rotates freely without separating it from Body A.
- **3.** Using an adjustable wrench, tighten **Body A** into equipment to manufacturer's specification.

Using a 3/4" open end wrench, tighten **Body B** into equipment to manufacturer's specification.

Align equipment. Hand tighten the coupling nut to secure locked position. The 36 internal locking teeth will engage during this process. While using a wrench to hold **Body A** from rotation, use a second wrench to tighten the coupling nut securely.

4. Tighten the center conductor seizure screws and replace the portcaps.



